



1. H.V. phase plug-in bushing
2. H.V. neutral plug-in bushing
3. Tap changer on Reactor
4. Earthing terminal
5. Oil drain valve
6. Lifting lugs
7. Oil level indicator
8. Diagram plate
9. Rated plate
10. Neutral to earthing connector
11. Contact thermometer
12. Filling tube
13. Cable box
14. Pressure guard

A	B	C	k	n	Mass(kg)	
					Oil	Total
960	980	1340	260	108	400	1700

SUBcomp 11/25-50