



1. H.V. Phase Plug-in bushing
2. H.V. neutral Plug-in bushing
3. Earthing terminal
4. Oil drain valve
5. Lifting lugs
6. Oil level indicator
7. Diagram plate
8. Rated plate
9. Neutral to earthing connector

kVA	A	B	C	d	e	g	l	m	k		n		Mass(kg)	
									H.V.	L.V.	H.V.	L.V.	Oil	Total
-	1100	1140	1400	-	-	-	-	-	260	-	108	-	500	1450